

2190 Dagenais Blvd. West Tel.: 514.337.4415 Laval (Quebec) Fax: 514.337.4029 Canada info@burcam.com H7L 5X9 see us at www.burcam.com

We recommend that a licensed electrician be employed to do wiring to the pressure switch. Permanently ground the motor in accordance to the electrical codes for your area.

Do not use an extension cord to connect your pump to the power source. From your distribution panel to the pressure switch, install a wire gauge no smaller than 14 gauge. See the wire chart for wire length above 100'.





MODEL 125335H

CONTROL BOX CONNECTION

> Please read these instructions carefully. Failure to comply to instructions and designed operation of this system, may void the warranty.

WIRE CHART						
		GAUGE				
HP	V	1 <u>4</u>	<u>12</u>	<u>10</u>	<u>8</u>	<u>6</u>
1/2	115	100'	160'	250'	390'	620'
1/2	230	400'	650'	1020'	1610'	2510'
3/4	230	300'	480'	760'	1200'	1870'
1.0	230	250'	400'	630'	900'	1540'
1.5	230	190'	310'	480'	770'	1200'
* If you need other configuration, contact us						





Use this section to connect your wires.

2 wires from the pressure switch, not polarised.

THESE **INSTRUCTIONS ARE VALID FOR** 3 WIRE (+ GROUND) **DEEP WELL PUMP** INSTALLATION.